



## Kubota Emulator Settings

Using the provided cable, connect to the emulator to set for Kubota or Cat engine:

- For Kubota engine Set KPBS to "1" for 250 - LED will blink once for 250
- For Cat engine Set KPBS to "2" for 500 - LED will blink twice for 500

